

DUNDEE DECO GRASSCLOTH WALLPAPER INSTALLATION INSTRUCTIONS

PLEASE NOTE: THESE NATURAL FIBERS ARE FRAGILE (ESPECIALLY AT THE EDGES OF EACH ROLL) - HANDLE WITH CARE!

1. Before installation: use pre-wallcovering primer on all surfaces. Allow the primer to dry completely prior to hanging.
2. Low water content glue is recommended.
3. Cut the desired length of wallpaper to fit the surface height, it is essential to use a sharp blade for the cutting, as a blunt blade will tear the natural fibers.
4. Apply wallpaper glue to the wall and a bit of the same glue to the back of the wallpaper, allow to absorb for 10-20 minutes and then stick it to the wall.
5. It should be noted that unlike traditional wallpaper, the glue cannot be removed from the front side of the natural Grasscloth wallpaper without leaving a mark, so ensure that no excess glue touches the front of the wallpaper after the wallpaper is stuck to the wall.
6. Do not use a hard roller on the Grasscloth wallpaper, it will damage the natural fibers, gentle pressure should be applied to the seams by hand or with a soft roller.

